



Assemblies should be tested after installation and before they are put into service.

After completing the Backflow Assembly Installation Inventory Form and performing the new test on each assembly these forms must be submitted to the Water/Sewer Maintenance Division at City of Statesville, P. O. Box 1111, Statesville, NC 28687-1111.

Any questions should be directed to Regina Hoke at 704-832-3847

Part of the Statesville City Code regarding Backflow Assemblies is printed below for your reference.

ARTICLE VIII. CROSS-CONNECTION, BACKFLOW AND BACK-SIPHONAGE CONTROL

Sec. 23-301. Intent, purpose and control.

(a) It is the intent of this article to recognize that there are varying degrees of hazard to potable water within the water main and water supply systems. It is also the intent to apply the principle that the degree of protection should be commensurate with the degree of hazard.

(b) The purpose of this article is to:

(1) Protect the public potable water supply of the city against actual or potential cross-connections, backflow, and back-siphonage by isolating within the premises of private property contamination or pollution that has occurred or may occur because of some undiscovered or unauthorized cross-connection on the premises of private property;

(2) Eliminate cross-connections, backflow and back-siphonage of any other source of water or process water used for any purpose whatsoever which may jeopardize the safety of the public potable water supply of the city;

(3) Establish a cross-connection, backflow and back-siphonage control program.

(c) Cross-connection, backflow and back-siphonage control require cooperation between the city and the consumer. The responsibilities and duties of each shall be as set forth in this article and other applicable regulations.

(Code 1959, § 21-56)